ASSEMBLY/INSTALLATION INSTRUCTION



Please read carefully before installation SAVE THESE INSTRUCTIONS



Underwater Lights

Assembly Instructions

This fixture is designed for underwater use.

- 1- To install bulb: Un-screw faceplate, by rotating it counter clockwise, take off the lens and gasket.
- 2- Push bulb pins in socket holes carefully until seated.
- 3- Put back lens and gasket in place. Then screw faceplate back onto housing, by rotating it clockwise.

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY TO PERSONS.

IMPORTANT SAFETY INSTRUCTIONS LIGHTED LAMP IS HOT!

Warning: TO REDUCE THE RISK OF FIRE OR INJURY TO PERSONS:

- Turn off/unplug and allow to cool before replacing lamp.
- Lamp gets HOT quickly! Contact only switch/plug when turning on.
- Do not touch hot lens, guard or enclosure.
- Keep lamp away from materials that may burn.
- Do not touch the lamp at any time. Use a soft cloth. Oil from skin may damage lamp.
- Do not operate the luminaire fitting with a missing or damaged shield

Application:

To be used in fountains, ponds, and waterfalls.
 DO NOT use in swimming pools, lakes and spas.

Installation Instructions

Fixture(s) should be used "ONLY" with low voltage landscape power units that do not exeed 25A, 15V.

The power units reduce the voltage from 120 volts to 12 volts.

The main cable can be purchased from your local electic supply house.

Caution:

Fixture(s) must be installed in accordance with all local codes and ordinances.

1. Attach fixture(s) wires to main cable with cable connector suitable for direct burial.

Gasket Lens MR-16 Lamp Housing Fixture Wire Base 12V MR-16 35W MAX LAMP



SAVE THESE INSTRUCTIONS

Limited Warranty

Corona Lighting warrants its products to be free of defects in material and workmanship under normal use, when installed in accordance with installation instructions, specifications and accepted trade practices as follows:

- Brass, copper, and stainless steel fixtures: Limited lifetime warranty from date of invoice.
- LED Integrated Fixtures: Ten years warranty from date of invoice.
- Aluminum Fixtures (Architectural Grade): Five years warranty from date of invoice.
- Composite Fixtures (Architectural Grade): Ten years warranty from date of invoice.
- Aluminum & Composite Fixtures (Value Grade): One year warranty from date of invoice.
- LED Lamps: Five years warranty from date of invoice.
- Transformers: Ten years on coils, Lifetime warranty on Stainless Steel enclosure, and one year warranty on timers, photocells, and accessories; from date of invoice.

This warranty excludes:

- 1. Products not used in accordance with directions specified in installation instructions and subject to unauthorized repair.
- 2. Damages caused by accident, altercation, misuse, abuse and exceeding the cost of product.
- 3. Costs incurred in shipment, repair, replace, remove or install of product by buyer and others.

Other Conditions

- Corona Lighting reserves the right to issue credit, repair or replace the defective product at our option upon receipt of
 written notification by original buyer of the alleged defect. Corona Lighting assumes no responsibility for improper
 installation of the product and shall not be liable for any incidental or consequential damages resulting from use of this
 product.
- Corona Lighting does not authorize any other warranty, verbal or written except as described here.
- Corona Lighting reserves the right to make any changes to its products without prior notice.

Visit Coronalighting.com for additional information on these and other products. Corona Lighting, Inc.; Los Angeles, California