


CL-398-BZ

LED Integrated Rail Light

WARRANTY- Ten years warranty from date of invoice.

RATED LIFE- 50,000 hours

Please read carefully before installation SAVE THESE INSTRUCTIONS



Assembly Instructions

- Drill a hole on wall and get the wire cord through the hole and out the wall.
- Remove the stainless steel bracket and "U" shaped cover from the fixture and mount the housing with two (2) screws on ceiling of wall cap. Connect the wire cord to the main cable. Then, connect main cable to power unit.

Installation Instructions

- Fixture should "ONLY" be used with low voltage landscape power units that do not exceed 25A, 18V
- The power units reduce the voltage from 120 volt to 12 volt.

10' wire cord -

Wall Cap

Single core LED

Mounting Screws

 $(\circ$

Hole for

wire cord

WALL

CL-398 housing -