



ASSEMBLY/INSTALLATION INSTRUCTION

Please read carefully before installation  
SAVE THESE INSTRUCTIONS



Bluetooth  
Mini Beam Light




INSTRUCTIONS PERTAINING TO A RISK OF  
FIRE, OR INJURY TO PERSONS

Warning: TO REDUCE THE RISK OF FIRE OR  
INJURY TO PERSONS:

Assembly Instructions

- 1. Bend the stainless steel stake into the desired shape to make sure the luminaire faces the correct direction or keep the stake straight
- 2. Attach fixture wires to main cable with cable connector suitable for direct burial.
- 3. Dig a small hole and insert fixture bracket into ground and turn on power unit.

Warning: Fixture wires have to be run in close proximity to fixture and not buried more than 3 inches.




Installation Instructions

Fixture should be used “ONLY” with low voltage landscape power units that do not exceed 25A, 15V.

The power units reduce the voltage from 120 volts to 12 volts.

The main cable from power units should be buried for less than 6 inches under the ground level and can be purchased from your local electric supply house.

Luminaire must be installed in accordance with the National Electrical Code (NEC) and local codes. Failure to do so will void the warranty and may result in serious injury and/or damage to the luminaire.



SAVE THESE INSTRUCTIONS

Limited Warranty

Corona Lighting warrants its products to be free of defects in material and workmanship under normal use, when installed in accordance with installation instructions, specifications and accepted trade practices as follows:

- Brass, copper, and stainless steel fixtures: Limited lifetime warranty from date of invoice.
- LED Integrated Fixtures: Ten years warranty from date of invoice.
- Aluminum Fixtures (Architectural Grade): Five years warranty from date of invoice.
- Composite Fixtures (Architectural Grade): Ten years warranty from date of invoice.
- Aluminum & Composite Fixtures (Value Grade): One year warranty from date of invoice.
- LED Lamps: Five years warranty from date of invoice.
- Transformers: Ten years on coils, Lifetime warranty on Stainless Steel enclosure, and one year warranty on timers, photocells, and accessories; from date of invoice.

This warranty excludes:

- 1. Products not used in accordance with directions specified in installation instructions and subject to unauthorized repair.
- 2. Damages caused by accident, altercation, misuse, abuse and exceeding the cost of product.
- 3. Costs incurred in shipment, repair, replace, remove or install of product by buyer and others.

Other Conditions:

- Corona Lighting reserves the right to issue credit, repair or replace the defective product at our option upon receipt of written notification by original buyer of the alleged defect. Corona Lighting assumes no responsibility for improper installation of the product and shall not be liable for any incidental or consequential damages resulting from use of this product.
- Corona Lighting does not authorize any other warranty, verbal or written except as described here.
- Corona Lighting reserves the right to make any changes to its products without prior notice.

Visit [Coronalighting.com](http://Coronalighting.com) for additional information on these and other products.  
Corona Lighting, Inc. ; Los Angeles, California